

One Year Limited Warranty

Hollywood Controls Inc ("the Company") warrants the HC0105B PB Hand Trigger & HC0120R Foot Pad Trigger against defects in material or workmanship for one year from date of original purchase. The Company, at it's option, will repair or replace the components and return them to you free of charge.

This warranty is extended only to the original purchaser on record with the Company.

Your remedy is limited to this warranty policy. This warranty only covers product failure that occurs due to defects in material and workmanship occurring during the normal expected use of the product. It does not cover damage caused by accident, misuse, abuse, lack of reasonable care, alterations or improper installation.

There are no expressed warranties except as described above.

THE COMPANY SHALL NOT BE LIABLE FOR INCIDENTAL, SPECIAL OR CONSEQUENTIAL DAMAGES RESULTING FROM THE USE OF THIS PRODUCT OR ARISING OUT OF ANY BREACH OF THIS WARRANTY. ALL IMPLIED WARRANTIES, IF ANY, INCLUDING IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED IN DURATION TO THE DURATION OF THIS EXPRESS WARRANTY. Some states do not allow the exclusion or limitation of incidental or consequential damages, or limitations on how long an implied warranty lasts, so

the above exclusions or limitations may not apply to you.

No other warranty, written or verbal, is authorized by the Company. This warranty gives you specific legal rights and you may also have other rights which vary from state to state.

For service during the warrantee period you must first contact the Company for an Return Merchandise Number (RMA) number. The Company will help you determine which part requires service and ask that you return that component ONLY. The Company, at it's option, will repair or replace the components and return them to you free of charge. All returned components must be accompanied by a RMA number issued by the Company and be returned by insured prepaid freight. Products returned without a Company issued RMA will not be accepted. The Company is not responsible for merchandise damaged in transit. Evident or concealed damage made in transit should be reported at once to the delivery carrier and a claim filed with them.

The Company reserves the right to change or modify the operation, design, components and description of this system without notice.

HOLLYWOOD CONTROLS, INC.

Phone: 888-318-2380

Fax: 888-517-5310

E-mail: sales@hollywoodcontrols.com



Hollywood Controls, Inc.

Hand & Foot Remote Triggers

Model: HC0105B Push Button Hand Trigger
HC0120R Large Foot Pad Trigger



Features:

- Industrial Quality
- Very Rugged
- RCA Plug Interface

Index:

Safety Precautions	1
General Description	1
Warrantee	2

General Description

The HC0105B & HC0120R are manual triggering devices for use with our HC1414 PowerBlaster series, HC2100 series Event Timers, HC2210 Power relay series or any other devices suitably activated by a low power contact closure.

Both come equipped with rugged molded RCA plug interfaces for quick and reliable connections. Readily available RCA adapters quickly convert the cords to other connector types or to bare wire interfaces.

The HC0105B Push Button Trigger has a 18' cord while the HC0120R 17" x23" Foot Pad is equipped with an ~20' cord.

Safety Precautions

- DO NOT alter or remove labels.
- Keep dry.
- DO NOT connect to devices supplying power to the RCA plug.

One Year Limited Warranty

Hollywood Controls Inc ("the Company") warrants the HCO105B PB Hand Trigger & HCO120R Foot Pad Trigger against defects in material or workmanship for one year from date of original purchase. The Company, at it's option, will repair or replace the components and return them to you free of charge.

This warranty is extended only to the original purchaser on record with the Company.

Your remedy is limited to this warranty policy. This warranty only covers product failure that occurs due to defects in material and workmanship occurring during the normal expected use of the product. It does not cover damage caused by accident, misuse, abuse, lack of reasonable care, alterations or improper installation.

There are no expressed warranties except as described above.

THE COMPANY SHALL NOT BE LIABLE FOR INCIDENTAL, SPECIAL OR CONSEQUENTIAL DAMAGES RESULTING FROM THE USE OF THIS PRODUCT OR ARISING OUT OF ANY BREACH OF THIS WARRANTY. ALL IMPLIED WARRANTIES, IF ANY, INCLUDING IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED IN DURATION TO THE DURATION OF THIS EXPRESS WARRANTY. Some states do not allow the exclusion or limitation of incidental or consequential damages, or limitations on how long an implied warranty lasts, so

the above exclusions or limitations may not apply to you.

No other warranty, written or verbal, is authorized by the Company. This warranty gives you specific legal rights and you may also have other rights which vary from state to state.

For service during the warrantee period you must first contact the Company for an Return Merchandise Number (RMA) number. The Company will help you determine which part requires service and ask that you return that component ONLY. The Company, at it's option, will repair or replace the components and return them to you free of charge. All returned components must be accompanied by a RMA number issued by the Company and be returned by insured prepaid freight. Products returned without a Company issued RMA will not be accepted. The Company is not responsible for merchandise damaged in transit. Evident or concealed damage made in transit should be reported at once to the delivery carrier and a claim filed with them.

The Company reserves the right to change or modify the operation, design, components and description of this system without notice.

HOLLYWOOD CONTROLS, INC.

Phone: 888-318-2380

Fax: 888-517-5310

E-mail: sales@hollywoodcontrols.com



Hollywood Controls, Inc.

Hand & Foot Remote Triggers

Model: HCO105B Push Button Hand Trigger
HCO120R Large Foot Pad Trigger



Features:

- Industrial Quality
- Very Rugged
- RCA Plug Interface

Index:

Safety Precautions	1
General Description	1
Warrantee	2

General Description

The HCO105B & HCO120R are manual triggering devices for use with our HC1414 PowerBlaster series, HC2100 series Event Timers, HC2210 Power relay series or any other devices suitably activated by a low power contact closure.

Both come equipped with rugged molded RCA plug interfaces for quick and reliable connections. Readily available RCA adapters quickly convert the cords to other connector types or to bare wire interfaces.

The HCO105B Push Button Trigger has a 18' cord while the HCO120R 17" x23" Foot Pad is equipped with an ~20' cord.

Safety Precautions

- DO NOT alter or remove labels.
- Keep dry.
- DO NOT connect to devices supplying power to the RCA plug.